

Trantec S5.3 / 5.5 Band G 606 - 622MHz (5.3) & 606 - 638MHz (5.5) Frequency chart. EBU TV Channels 38 - 39 (5.3) & 38 - 41 (5.5)

Channel	Bank 1	Bank2	Bank3	Bank4	Bank 5	Bank 6	Bank 7	Bank 8	Bank 9	Bank 10 USER
1	606.600	606.600	606.950	607.825	606.600	606.600	606.600	606.500	606.225	606.750
2	607.500	607.500	608.500	608.825	607.500	607.500	607.300	607.600	606.550	607.475
3	608.150	608.150	609.500	610.250	608.150	608.150	607.800	608.250	607.000	607.900
4	609.150	609.150	611.600	610.900	609.150	609.150	608.100	609.875	608.350	609.175
5	609.950	609.950	611.950		609.950	609.950	608.725	610.275	609.025	609.650
6	610.550	610.550	612.750		610.550	610.550	609.500	611.025	609.400	610.650
7	611.250	611.250			611.250	611.250	609.875	612.425	610.775	611.950
8	612.300	612.300			612.300	612.300	610.450	612.800	611.675	614.150
9	613.150	613.150			613.150	613.150	611.525	613.375	612.775	615.050
10	613.500	613.500			613.500	613.500	612.275	614.225	613.725	615.750
11		617.600			614.875	616.150	612.700	614.725		617.525
12		618.550			616.150	617.575	613.375	615.450		617.850
13					619.050	618.525		617.850	622.125	618.900
14					620.925	619.850		618.925	622.600	624.275
15					621.325	625.600		619.450	623.350	624.950
16					623.350	626.100		619.750	624.200	626.400
17					624.450	627.550		620.425	626.100	627.275
18					625.200	628.175		620.750	626.500	628.400
19					626.075	630.850		621.300	627.225	631.350
20					626.375	632.475			628.700	631.725
21					627.150	632.850			629.400	632.925
22					628.575	633.975			629.950	633.750
23					629.300	635.350				636.000
24						636.275				636.800
	JFMG Set	JFMG Set 2 from 39	JFMG Set Ch 38 Broadcast	JFMG Set Ch 38 Community	JFMG Set 39 & 40	JFMG Set 39, 40, 41 & 42	Ch 38 Trantec	Ch 38 & 39 Trantec	Ch 38 & 40 Trantec	Ch 38, 39 40 & 41 Trantec (S5.5 only)

Please note: Frequencies are compatible within each bank only. Do not mix banks in multi-channel operation